



2004 Henry Parkway Connector  
McDonough, GA 30253  
Phone: 1-866-306-6568  
Fax: 770-507-5827  
www.KMTSystems.com

---

---

## How Do I Calibrate my 888 Door Lock?

If you encounter the door lock jamming or not opening or closing properly, you can calibrate the lock and fix the problem most of the time.



Complete the following steps to calibrate your 888-Door Lock:

1. Unlock the door with the thumb lever on the inside of the door
2. Remove the back black cover
3. Remove the battery pack
4. Press and release the lock icon button on the exterior of the door (you will hear a faint beep)
5. Press and hold the lock icon button
6. Insert the battery pack
7. Release the lock button when the battery pack is inserted completely and quickly press and release the lock button once more
8. The lock will go through a reset process, you will hear a click, then the lock will lock, then a second click then a beep
9. The calibration is complete

**TIP:** when starting on step 6 hold the battery pack in the slot partially and have your finger on the lock button holding it down. Drop the battery pack in the slot, release the button and repress within a second and it will start the process.